


END UNIT - FIRST FLOOR

Scale : 1/4" = 1'-0"
 0' 0" 1' 0" 2' 0" 3' 0" 4' 0" 5' 0"



END UNIT - SECOND FLOOR

Scale : 1/4" = 1'-0"
 0' 0" 1' 0" 2' 0" 3' 0" 4' 0" 5' 0"